













Rolka KMA 50
Furniture caster KMA 50
Колёсики KMA 50



					
KM-A050MM-00	bez hamulca without break без стопора	50	35	przeźroczysty / transparent / прозрачный	PC / PU
KM-A050MM-30				brąz / brown / коричневый	
KM-AH50MM-00	z hamulcem with break со стопором			przeźroczysty / transparent / прозрачный	
KM-AH50MM-30				brąz / brown / коричневый	

Rolka SHIFT 50
Furniture caster SHIFT 50
Колёсики SHIFT 50



					
KM-B050MM-00	bez hamulca without break без стопора	50	30	przeźroczysty / transparent / прозрачный	PC / PU
KM-B050MM-30				brąz / brown / коричневый	
KM-BH50MM-00	z hamulcem with break со стопором			przeźroczysty / transparent / прозрачный	
KM-BH50MM-30				brąz / brown / коричневый	